



Using your iPhone with fring™ and Skype™ over Spot On Networks

Many properties have poor cell phone coverage, making it difficult to make and receive calls while in your apartment. Now, there is an application for the iPhone, called **fring™**, which allows you to make and receive Wi-Fi calls via your **Skype™** account through the Spot On Wi-Fi service available at your property.

This application does not require “hacking” the iPhone. Rather, by forwarding your cell phone number on no service to your **Skype™** number, you can make and receive calls over Wi-Fi even when you have no cellular coverage. This approach also allows you to save cellular minutes by utilizing Spot On’s Wi-Fi network throughout your community. This document tells you how to set it up.

1.0 About fring™ and Skype™

The **fring™** application is a mobile Internet service that enables you to make and receive Wi-Fi calls via **Skype™** on cell phones certified by fring™. (Please see <http://www.spotonnetworks.com> for a complete list of **fring™** certified phones.)

Once you’ve installed **fring™**, the main screen displays your contacts and their online / offline status. This list shows the names of your friends and your Skype contacts.

fring™ is required because it is the only iPhone application currently available to utilize **Skype™** over Wi-Fi.


Skype™ provides easy, low-cost calls to landlines and cell phones around the world. You can also forward a call to your mobile; send a text message directly from **Skype™**, or set up an online number for friends, family and colleagues to make a local call from their phone to your **Skype™** number, wherever in the world you are.

2.0 Sign up for Spot On Service

Your iPhone needs to be authorized to access the Spot On wireless network in your community. Please call Spot On Networks’ customer support at 87-SPOTON-87 (877-768-6687) to sign up for access. If you have a pre-existing Home Spot, Pro Spot, Power Spot, or SoHo Spot account and have not used all of your sub-accounts, your phone can be added to your existing account for free. Otherwise, you can call Spot On Networks to set up a new account .

When you call Spot On Networks, please make sure to have the MAC address of your iPhone available. You can find your MAC address as follows:





4. The **Wi-Fi Address** (MAC Address) is located on the **About** control panel.

3.0 Sign Up for Skype™ Service

If you already have a Skype account with Skype In, you may skip this step.

1. Connect to your Spot On wireless account.
2. In your browser, go to <http://www.spotonnetworks.com/> and click on “Skype”
3. On the top of the Skype web page, click the “**Get Connected**” tab.
4. Follow the instructions to sign up for a Skype account. This will allow you to make unlimited outgoing Wi-Fi calls for \$2.95/month in the US and Canada Make sure your subscription also includes “**Skype In**” to receive unlimited incoming Wi-Fi calls, for an additional \$3.00/month Skype has additional rate plans available (e.g. international) Please make sure you have your credit card or PayPal account available.
5. Note down your Skype User ID and password so that you can enter it when prompted by fring™. Also note down your Skype In phone number to be used for call forwarding.

4.0 Download and Install fring™

1. On your iPhone, launch the “**App Store**” and search for “**fring**”.
2. Download the **fring™** application to your iPhone.
When the installation is complete, the “Installation Complete” message will appear.
3. Launch **fring™**.
A screen will appear asking you if you are a new or existing member.




Figure 1. Select Whether You Are An Existing User or New User

4. If you have used **fring™** in the past, click **“Existing”** and enter your **fring™** credentials. Otherwise click **“New”**
5. On the **“Account Setup”** screen, select a **“User ID”**, **“Nickname”**, **“Password”**, and enter your **“Email address”**.
6. Click **“Register”**.




Figure 2. The Account Setup Screen

7. Add your Skype account details in the **“Add-ons”** screen by clicking **“more”**.
Note: Have your Skype User ID and password information ready when you connect via **fring™**.
8. In the **“Add-ons”** window, check Skype. You will be prompted for your login information.



Figure 3. The Add-ons Screen is Where VoIP Account Details Are Added



Figure 4. Prompting for User ID and Password

9. In the “**User ID**” field, type your Skype username.
10. In the “**Password**” field, type your Skype password.
11. Touch “**Login**”.

When the sign-in is complete, the “**Buddy list**” of your Skype contacts appear in the fring™ application.



Figure 5. The Skype Buddy List Appear in the fring™ Application

5.0 Making and Receiving Wi-Fi Calls

Make sure your iPhone is connected to a SpotOn Wi-Fi network and that **fring™** is running in order to make and receive calls over Wi-Fi.

5.1 Making Wi-Fi Calls

When the installation and registration processes described above are completed, you are ready to make your first call. To assure yourself that everything is working correctly, you can call the fring™ Test Center. Make the test call as described below:

1. From your **"Buddy list"** choose the **fring™ test call** contact.
2. Press the Call button on the second screen.
3. The call connects to the test center.
4. Listen to the message and follow the instructions.
Your testing is complete!
5. Tap the **"Dialer"** button to get a keypad.



Figure 6. The fring™ Keypad

The **"Cellular"** button will be bright green. The **"Skype Out"** button will also be bright green, if you have successfully signed into Skype.

6. When making a **"Skype Out"** call, make sure that you include a **"+1"** and then the area code and number.

Note: The **"+"** appears when you hold down the **"0"** button for a few seconds.

5.2 Receive Wi-Fi Calls

In order to receive cell phone calls through your Skype account, you must first do a one-time forwarding of your cell phone number to you Skype number when there is no cellular signal.

1. Using the normal iPhone dialer, dial the following number to forward all calls on "unreachable" from your cell phone to your **"Skype In"** number, making certain to include the asterisk (*) before and after **62** and **#** at the end:
 - a. Dial ***62*1naanxxxnxxx#**, where 1-(naa) nxx – nxxx is your **"Skype In"** number.




Figure 7. Setting Up to Forward All Calls

You will receive a confirmation screen indicating success that the calls have been forwarded on “**unreachable**”. Your phone calls are now forwarded to your “**Skype In**” number when the phone is “**unreachable**”, such as when you are in a no-service area.



Figure 8. The Confirmation Screen

You can reverse this procedure at any time by dialing **##62#**.

3. Run the **fring**[™] application and await a Wi-Fi call.

If you are interested in more advanced forwarding features, go to <http://www.spotonnetworks.com/> or call Spot On customer support at 87-SPOTON-87 (877-768-6687).

5.3 Important Notes About Using fring™ on your iPhone

1. **You do not need to distribute your “Skype In” number to your contacts in order to receive Wi-Fi calls. All calls will appear to be coming from or going to your cell phone number.**

With the forwarding procedure in Section 5.2, anyone dialing your cell phone will reach your Wi-Fi “Skype In” account.

Similarly, when you configure your Skype account for Skype In, your caller ID for outgoing calls can be set to show your cellular number. Follow Skype’s instructions to set this up.

2. **To receive Wi-Fi calls, fring™ must be running.**

The iPhone is not capable of running multiple 3rd party applications at once, so **fring™** cannot run in the background.

If you are using other applications on your iPhone, you will not receive Wi-Fi calls, and any incoming calls will go into your cellular voice mailbox.

3. **When locking your phone, leave fring™ running to receive Wi-Fi calls.**

When the iPhone is locked, **fring™** will continue to run as long as **fring™** was running when the phone was locked. Hence, you will still be able to receive Wi-Fi calls when the phone is locked.

If you have any other questions, please visit our website at <http://www.spotonnetworks.com/> or call customer support at 87-SPOTON-87 (877-768.6687).